



## IMPORTANT NOTICE CONCERNING WARRANTY SERVICE

Thank you for purchasing! Before using this charger, please find your verification code on the package box, and go to <http://charger.nitecore.com/validation> (or scan the QR code beside the verification code to visit on your mobile phone). Type in your verification code and personal information as required, and submit the page. After verification, Nitecore will send you a warranty service email. This email and your registration email address are essential to your possible warranty application. Before you complete the warranty service registration, you cannot enjoy our warranty service for your purchase.



# Intellicharger NEW i2

## User Manual

### Features

- Twice the charging speed of the i2 charger
- Active Current Distribution (ACD) Technology
- Compatible with 1.2V, 3.7V, 4.2V, 4.35V batteries
- Charging program optimized for IMR batteries
- Automatic current selection based on battery capacity
- Automatic detection of non-rechargeable batteries
- Capable of charging two batteries
- Two charging slots charge and control independently
- Automatically detects battery power status and displays charging progress
- Automatically stops charging upon charging completion
- Reverse polarity protection and short circuit prevention
- Over-discharged battery activation
- Overtime charging protection
- Designed for optimal heat dissipation
- Made from fire resistant, flame retardant PC material
- Certified by RoHS, CE, FCC and CEC
- Insured worldwide by Ping An Insurance (Group) Company of China, Ltd.

### Specifications

**Input Voltage:** AC 100~240V 50/60Hz 0.25mA(max) 8W  
DC 9~12V

**Output voltage:** 4.35V±1%/4.2V±1%/ 3.7V±1%/1.48V±1%

**Output current:** 500mAx2/1000mA x1

**Compatible with:**

**Li-ion/IMR/LiFePO4:**

10340, 10350, 10440, 10500, 12340, 12500, 12650, 13450, 13500, 13650, 14350, 14430, 14500, 14650, 16500, 16340(RCR123), 16650, 17350, 17500, 17650, 17670, 18350, 18490, 18500,18650, 18700, 20700, 21700, 22500, 22650, 25500, 26500, 26650

**Ni-MH(NiCd):** AA,AAA,AAAA,C,D

**Dimensions:** 132mmx70mmx35mm

**Weight:** 126g(without batteries and power cord)

### Operating Instructions

**Connect to power source:** Connect the NEW i2 to an external power source (such as car adaptor, power socket) via its charging cable.

**Install batteries:** Put one or two batteries in each independently-controlled slot according to the polar mark on the charger.

**Battery identification:** Four LEDs go up over the slot a Lithium battery is inserted in; two lower LEDs go up over the slot a Ni-MH battery is inserted in. Charging begins in two seconds.

**Battery inspection and report:** The NEW i2 automatically discriminates between rechargeable and non-rechargeable batteries. It automatically reports errors when non-rechargeable batteries are inserted, or batteries are short-circuited or inserted with polar reversed.

Battery Activation and Inspection	Error Report
Non-rechargeable batteries inserted	Four LEDs on the screen blink to notify the user of an error.
Batteries inserted with polar reversed	
Batteries short-circuited	
The NEW i2 will charge normal batteries upon inspection.	

**Smart charging:** The NEW i2 can choose charging currents based on intelligent detection about battery types and capacities. Manual charging current selection is also available. The NEW i2 is compatible with:

- 1) 3.7V Li-ion rechargeable batteries
- 2) 3.8V Li-ion rechargeable batteries
- 3) 1.2V Ni-MH/Ni-Cd rechargeable batteries
- 4) 3.2V LiFePO4 batteries

During charging, the three indicator LEDs indicate the batteries' status and charging percentages.

### Charging Current Settings

Install the batteries into the NEW i2, and press the button over the battery's slot after automatic detection to enter Manual Settings mode. Press and hold the C button to enter Current Selection to manually select 1A or 500mA charging current when a large capacity battery (>1200mAh). When the appropriate current setting is highlighted, release the C button and press the button over the slot again to exit Manual Settings mode and begin charging.

Battery Types and Capacity		Default Current		Manual Setting to 1A Available
		1 battery	2 batteries	
Lithium	>1200 mAh	1A	0.5A	Yes
	<1200 mAh	0.5A	0.5A	No
NI-MH		0.5A	0.5A	No

Active Current Distribution (ACD)			
1A Set	Left slot	1A Set	Right slot
Yes	Charges at 1A with priority	Yes	Holds while Left is charging; Charges at 500mA while Left is close to completion; Charges at 1A while Left is complete.
Yes	Charges at 1A with priority	No	Holds while Left is charging; Charges at 500mA while Left is close to completion; Charges at 500mA for small capacity battery while Left is complete; Charges at 1A for large capacity battery while Left is complete.
No	Holds while Right is charging; Charges at 500mA while Right is close to completion; Charges at 500mA for small capacity battery while Right is complete; Charges at 1A for large capacity battery while Right is complete.	Yes	Charges at 1A with priority

**Note:**

1. When 1A charging current is selected, the LED next to the 1A mark goes on.
2. For small capacity batteries (<1200mAh, such as 10440, 16340), 500mAh charging current is automatically selected.
3. For Ni-MH batteries and 3.7V Li-ion batteries, the NEW i2 automatically selects proper charging modes. For LiFePO4 batteries, manual setting is required.

### Charging Voltage Settings

**For LiFePO4 batteries:**

Insert the batteries into the NEW i2's charging slots. After battery inspection, press the button over the battery's slot to enter Manual Settings mode. Press and hold the V button to enter Voltage Selection. Before the button is released, three settings of charging cut-off voltages will cycle every second (highlighted with an LED). When the desired setting is highlighted, release the V button, and press the button over the slot again to exit Manual Settings mode and begin charging.

**For 3.8V Li-ion batteries:** Follow the above setting method.

### Battery Activation

The NEW i2 is capable of activating depleted Li-ion batteries with protective circuit. After battery installation, the NEW i2 will test and activate the battery before charging. A battery detected as damaged cannot be activated, and the three LEDs above its slot will go on to notify the user.

### Lithium Battery Recovery

Upon insertion of a 0V IMR battery, all four LEDs over its slot will blink to indicate that it is not ready for charging. Press and hold both buttons until its power indicator blinks to enter the Recovery mode. Nitecore recommends abandoning this battery if it fails to be recovered after several attempts.

**NOTE:** When attempting to activate an IMR battery, reverse polarity protection is temporarily disabled. Take special care to ensure batteries are correctly inserted. Failing to do so may result in fire and explosion.

### Overtime Charging Protection

The NEW i2 will separately calculate the charging time of each battery. When the overall charging time exceeds ten hours, the NEW i2 will automatically stop charging and display a fully charged status. This is to prevent possible overheating or even explosion due to battery quality issues.

### Precautions

1. The charger is restricted to charging Li-ion, IMR, LiFePO4, Ni-MH/Ni-Cd rechargeable batteries only. Never use the charger with other types of batteries as this could result in battery explosion, cracking or leaking, causing property damage and/or personal injury.
2. The safe operation temperature for the charger is between -10-40°C, and the safe storage temperature is -20-60°C.
3. Please charge batteries in accordance with the specifications on the back. Do not charge a battery pack with the charger.
4. Observe polarity diagrams located on the charger. Always place the battery cells with positive tip facing the top.
5. Do not leave a working charger unattended. If any malfunction is found, please terminate operation immediately, and turn to user manual for instruction.
6. The charger is for use of adults above 18 years old. Children under this age must be supervised by an adult when using the charger.
7. Please make sure the correct program and settings are chosen and set. Incorrect program or setting may damage the charger, or cause fire or explosion.
8. Never attempt to charge primary cells such as Alkaline, Zinc-Carbon, Lithium, CR123A, CR2, or any other unsupported chemistry due to risk of explosion and fire.
9. Do not charge a damaged IMR battery as doing so may lead to charger short-circuit or even explosion.
10. Never charge or discharge any battery having evidence of leakage, expansion/swelling, damaged outer wrapper or case, color-change or distortion.
11. Use the original adapter and cord for power supply. To reduce the risk of damage to the power cord, always pull by connector rather than the cord. Do not operate the charger if it appears damaged in any way.
12. Do not expose the device to direct sunlight, heating devices, open flames; avoid extreme high or extreme low ambient temperatures and sudden temperature changes.
13. Please operate the charger in a well-ventilated area. Do not operate or store it in damp area. Keep all the inflammable volatile substances away from operating area.
14. Avoid mechanical vibration or shock as these may cause damage to the device.
15. Do not short-circuit slots or other parts of the device. Do not allow metal wires or other conductive material into the charger.
16. Do not touch hot surfaces. The rechargeable batteries or the device may become hot at full load or high power charging/discharging.
17. Do not overcharge or over discharge batteries. Recharge drained batteries as soon as possible.
18. Remove all batteries and unplug the charging unit from the power source when not in use.
19. Opening, disassembling, modifying, tampering with the unit may invalidate its guarantee, check warranty terms.
20. Do not misuse in any way! Use for intended purpose and function only.

### Disclaimer

This product is globally insured by Ping An Insurance (Group) Company of China, Ltd. Nitecore shall not be held responsible or liable for any loss, damage or claim of any kind incurred as a result of the failure to obey the instructions provided in this user manual.

### Warranty Details

Our authorized dealers and distributors are responsible for warranty service. Should any problem covered under warranty occurs, customers can contact their dealers or distributors in regards to their warranty claims, as long as the product was purchased from an authorized dealer or distributor. NITECORE's Warranty is provided only for products purchased from an authorized source. This applies to all NITECORE products.

Any DOA / defective product can be exchanged for a replacement through a local distributor/dealer within the 15 days of purchase. After 15 days, all defective / malfunctioning NITECORE® products can be repaired free of charge for a period of 12 months (1 year) from the date of purchase.

Beyond 12 months (1 year), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified if the product(s) is/are

1. broken down, reconstructed and/or modified by unauthorized parties
2. damaged from wrong operations (i.e. reserve polarity installation, installation of non-rechargeable batteries), or
3. damaged by batteries leakage.

For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to [service@nitecore.com](mailto:service@nitecore.com).

※All images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occurs between this manual and information specified on [www.nitecore.com](http://www.nitecore.com), information on our official website shall prevail. Sysmax Industry Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.

### Safety Instruction for Lithium-ion Batteries

#### 1. Charging Voltage

Lithium-ion (Li-ion) batteries have strict requirement on voltage control. Charging Li-ion batteries with electric voltage beyond safety standard can lead to battery damage and explosion.

##### (1) 4.2V Li-ion Batteries/ IMR Batteries

4.2V Li-ion batteries are the most common rechargeable Lithium batteries. The skins of these batteries are often marked with 3.6V/3.7V signs. If our chargers judge that an inserted battery is a Li-ion battery, the battery will be automatically charged in 4.2V standard charging mode. You do not need extra voltage settings for these types of batteries.

##### (2) 4.35V Li-ion Batteries

4.35V Li-ion batteries are comparatively rare. It usually has a 3.7V mark on its skin. Normally its seller will inform its buyer that it needs to be charged with 4.35V power. When charging this type of battery, please manually set the charging voltage to 4.35V, otherwise the charger will charge at 4.2V by default, and cannot provide adequate charging voltage.

##### (3) 3.7V LiFePO4 Batteries

3.7V LiFePO4 batteries have LiFePO4 and/or 3.2V marks on the skin. Be careful with this type of batteries. Without manual setting, our chargers will charge this type of batteries with 4.2V voltage, and will damage or even explode the battery with excessive charging voltage. You need to manually set the charging voltage to 3.7V for safe charging.

#### 2. Charging Current

For all rechargeable Lithium batteries (including Li-ion, IMR and LiFePO4 batteries), we suggest not using current larger than 1C\* for charging. For small capacity batteries, the charging current must be smaller than 1C.

\*C=Capacity of a battery. For example, 1C in a 2600mAh rechargeable Lithium battery is 2.6A. 1C in a 3400mAh rechargeable Lithium battery is 3.4A.

Excessively large charging current will lead to great amount of heat, and consequently battery damage and explosion.

**Warning:** Our chargers automatically judge and select charging current by the batteries' length. For some long but small capacity batteries (i.e. 12650, 13650, 14650, 16650), please manually set appropriate charging current (smaller than 1C).

#### 3. Precautions

- (1) Do not short circuit the battery in any way.
- (2) Do not use a 4.2V/4.3V Lithium battery when its voltage is lower than 2.8V, otherwise it can be over-discharged, and/or prone to explosion at next charging.
- (3) We strongly recommend batteries with protective circuit. For batteries without protective circuit (such as IMR batteries), please stay alert for over-discharge and short circuit.
- (4) Do not discharge a battery with a discharging current larger than its maximum rated current.

#### 4. Long-term Storage

The best storage voltage for 4.2V/4.35V rechargeable Lithium batteries is 3.7V. Voltage too low or too high can damage your battery during storage. You can discharge a battery to 3.7V, or charge it to 3.7V in a charger before you keep it in long-term storage.

**Validation code and QR code on package can be verified on Nitecore website.**

**1. The charger must be used with Nitecore's official cords. Official cords are identified with clearly printed Nitecore on the plug. During charging, third party cords can cause malfunction, overheat and even fire on the charger. Damages from using unofficial cords cannot be covered by official warranty.**

**2. The NEW i2 is restricted to charging Li-ion, IMR, 3.7V LiFePO4, Ni-MH/Ni-Cd rechargeable batteries only. Never use the NEW i2 with other types of batteries as this could result in battery explosion, cracking or leaking, causing property damage and/or personal injury.**



SYSMAX Industry Co., Ltd.

TEL: +86-20-83862000

FAX: +86-20-83882723


E-mail: info@nitecore.com

Web: www.nitecore.com

Address: Rm1401-03, Glorious Tower, 850 East Dongfeng Road, Guangzhou, China 510600

Manufacturer: SYSMAX Power Technology, LLC

Address: B4 Happy Factory, 81 East Huahong Commercial Street, North Zhenxing Road, Gaobu, Dongguan, China



20160613

*Thanks for purchasing NITECORE!*